



Pond Safety 'Net'- DIY Installation Booklet

Thank you for purchasing the DIY Pond Safety Ltd. Net kit.

Dependant on the specification of your pond your DIY Pond Safety Ltd. Diamonddeck kit will comprise of the following;



Net
(A)



Anchor
(B)



Carabineer
(C)

You will also need:-



A Cordless Drill



Drill Bits*



Marking Tool



Hammer

* 6.5mm into Stone; 5mm into Aluminium; 6mm into Wood

N.B. DO NOT use electrical equipment near water



Pond Safety 'Net'- DIY Installation Booklet



Drill a hole at 0.5m intervals around the entire edge of the pond.

If the pond edge has corners, ensure that a hole is also drilled into the corner. This in addition to the holes at 0.5m intervals.



Using a hammer tap an Anchor (B) into each hole until just the eye of the Anchor (B) is visible above the surface.

N.B. Place a screwdriver into the eye of the Anchor (B) whilst tapping the Anchor (B) into the holes. This prevents the eye of the Anchor (B) closing when tapping with the hammer.



Clip a Carabineer (C) into each eye of the Anchors (B).

Position the Carabineers (C) so that the carabineer (C) clip catch is facing outwards towards the water.



Position the Net (A) over the entire pond surface ensuring that all carabiners (C) are covered underneath the Net (A).

Also ensure the squares within the Net (A) are kept as linear as possible.



Pond Safety 'Net'- DIY Installation Booklet



Starting with the corners, clip the Net (A) to the Carabineers (C).

N.B. Ensure to pull tightly and tension the Net (A) before clipping each corner whilst still maintaining the linear nature of the Net (A).



Select a Carabineer positioned in the middle of the pond; clip the Net (A) to the Carabineer (C).
At the opposite facing Carabineer (C) connect the Net (A) to the Carbineer (C).

Repeat the above until all middle Carabineers (C) are connected to the Net (A).

N.B. Ensure to pull tightly and tension the Net (A) before clipping each corner whilst still maintaining the linear nature of the Net (A).



Clip all remaining Carabineers (C) to the Net (A) ensuring to tension the Net (A) before clipping each Carabineer.

N.B. Ensure to pull tightly and tension the Net (A) before clipping each corner whilst still maintaining the linear nature of the Net (A).



Pond Safety 'Net'- DIY Installation Booklet

You should now have a Pond Safety Ltd. Net similar to the one below.



Extra Help?

We can always come and fit your Pond Safety Ltd. Net for you. Please call the office on 0800 169 6919 or 01623 438049 to obtain a quotation.

We also have helpful tips and pointers on YouTube.